


# Laser Welding Torch



Sr. No.	Parts Name
1	Nozzel AS-12
2	Nozzel BS-16
3	Nozzel CS-12
4	Nozzel ES-12
5	Nozzel FS-16
6	Nozzel C
7	Nozzel Cutting
8	Contact Tip 0.8
9	Contact Tip 1.2
10	Contact Tip 1.6
11	Tip Holder Tube 60mm
12	Tip Holder Tube 100mm
13	Focus Scale Tube FT70
14	Focus Scale Tube FT80
15	Focus Scale Tube FT125
16	Spring Seal 15*21*2.7
17	Focus Tube Nut
18	Cleaning Dust Cover
19	Focus Tube Chuck
20	Liner Fixing Plate

Sr. No.	Parts Name
21	Protective Lens D18*T2
22	Focus Lens D20*4.5*F150
23	Focus Lens D20*4.5*F200
24	Focus Lens D20*4.5*F400
25	Focus Lens D20*4.5*F800
26	Reflective Lens 30*14T2
27	Reflective Motor
28	Laser Torch Button
29	Collimating Lens D20*T5*F60
30	Collimating Lens D16*T5*F60
31	Wire Outlet Screw
32	Connecting Block
33	Liner 2.5mtr
34	Liner 5mtr
35	Wire Feeder Roller 0.8 - 1.0
36	Wire Feeder Roller 1.2 - 1.6
37	Cleaning Buds / Swabs
38	Torch Safety Cover 10Mtr
39	Torch Head Cover
40	Ground Clip / Clamp